





Installation Manual







① X1pc




② X1pc




③ X1pc



④ X1pc




⑤ X1pc



⑥ X1pc




⑦ X1pc




⑧ X1pc




Ⓐ X15pc



Ⓑ X4pc





Ⓒ X1pc




Ⓓ X1pc




1



 	 ⒷX4pc
---	---



3



Tighten all screws to 100% after inspection.

