

USE AND MAINTENANCE


Use on level surfaces only

Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly


Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

Triple Cat Tower


PART LIST




1 - First Floor x1



2 - Second Floor x1



3 - Third Floor x1



4 - Supporting Plate x1



5 - Support x1



6 - Cat Tree x 2

HARDWARE



A - Screw x 9




B - Screw x 1




C - Hex Screwdriver x 1


Assembly Instructions



1. Select 3×1, 4×1, 5×1, 6×2, A×6, B×1. Insert 5×1 and 6×2 into the 4 with A ×2, B×1. Install the 3 into the 5 and 6×2 with the A ×3.



2. Insert the 2 into the Between of 6×2 with the A×2.



3. Insert the 1 into the Top of 6×2 with the A×2.

Congratulations! Setup of your new Triple Cat Tower is Complete!

