

ASSEMBLY INSTRUCTION

Slated 4-Shelf Folding Bookcase

WARNING:
Shelves Can Be Unfold




Diagram1.

Step 1.

Rest the unit on a soft surface. Unfold the front frame, careful to keep the shelves in place per Diag.1.




Diagram3.

Step 3.

Unfold other shelves to lock the pinball into the hole at each crossbar of the front frame as per Diag. 3.




Diagram2.

Step 2.

Unfold the bottom shelf and lock the pinball into the hole on the bottom crossbar of the front frame as per Diag. 2.




Diagram4.

Step 4.

Use L-brackets (RF50003) and screws F6 x 5/8" (RF10004) to attach two side panels to the studs in the wall, using screws F6 x 1 1/4" (RF10002) as per Diag. 4.

Anti-Tipping

NO	DESCRIPTION	Q'TY
F10004	 Screws F6 x 5/8"	4
F10002	 Screws F6 x 1 1/4"	2
F50003	 L-Bracket	2