


# Installation Manual





---

GK01




# Components list

---




# Pre-installation


## TOOLS REQUIRED



## HARDWARE INCLUDED




To provide feedback on a particular part, please mark it by circling in the instruction manual and kindly send us a photo.




## Pre-installation

**1**


Measure width of gate opening and cut horizontal 2x4's 1 " (2.5 cm) shorter than opening. Attach to brackets use included screws.





ST4.8x38(x3)



ST4.8x38(x3)



ST4.8x38(x6)




# Installation


2

Cut vertical 2x4's to desired height and attach to brackets use included screws.


A



(x1)




ST4.8x38(x7)




(x1)

C




(x2)




ST4.8x38(x6)


B









(x1)



ST4.8x38(x7)



(x1)



# Installation

**3**

Attach fence boards to correct side of gate frame according to desired swing direction.  
Attach gate hinges to fence post use included screws.

**A**



ST4.8x38(x4)

**B**



ST4.8x38(x4)

