




ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

215974
Mirror

ITEM: 215974

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A MIRROR

1PC




B DRESSER FROM BOX
ITEM #215973

1PC



C MIRROR SUPPORT
(PACKED WITH DRESSER)

2PCS



HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW
(M4 x 32mm - RBW)



10PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **215974**


ASSEMBLY INSTRUCTIONS

STEP 1





****BACK VIEW****


STEP 2



STEP 3 COMPLETE



ITEM: **215974**



Note : Dimension tolerance $\pm 5\%$