



Assembly Instructions




SHOULD YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OR PARTS OF YOUR NEW ECCOSTYLE ITEM, PLEASE DO NOT RETURN TO THE STORE, INSTEAD CALL 1-360-883-6082 OR WRITE TO: CUSTOMERSERVICE@CASUALCONTEMPORARYLIVING.COM


Why eccostyle bamboo?

- Renewable resource – Bamboo has the Fastest Growing Cycle of any furniture raw material – 5 years sprout to harvest.
- Bamboo also has superior structural strength as well as the lowest moisture expansion/contraction displacement of any furniture raw material 50% lower than Oak or Pine
- Environmentally desirable UV activated finish – virtually 100% of the finish is utilized without spray or runoff waste and it dries instantly when exposed to UV Light without heat.


Before Assembly — Please place all parts onto a clean dry and soft surface to avoid damage during the assembly of your furniture.

www.CasualContemporaryLiving.com







1




2




3



4



5



6