
Assembly Instructions

Caution: You must read this before you proceed

Sofa



Parts List				
Label	Picture	Description	QTY	
А		Sofa Seat	1	
В	<u> </u>	Sofa Backrest	1	
С		Right Arm Panel	1	

D		Left Arm Panel	1		
E		Middle Support Legs	2		
Hardware					
Label	Picture	Description	QTY		
1		Bolt (M8*50MM)	12		
2		Washer	12		
3	0	Spring Washer	12		
4		Allen Wrench	1		
5		Washer Ring	2		
Assembly Preparation					
Before Beginning Assembly:					



Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-


Assembly Steps

Overview



This Sofa has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Sofa parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise yourself with the parts and steps before assembly.





Open the carton and place all the parts on a clean, non-marring surface.

With the assistance of your partner, slide the Tapered Connectors on the Left Arm Panel(D) into the Tapered

Connectors on the Sofa Backrest (B) as shown in the picture.

Repeat the same process with the Right Arm Panel(C).

Note: Make sure the Tapered Connectors on the Left Arm Panel(D) and Right Arm Panel(C) lock into the

Tapered Connectors on the Sofa Backrest (B).


Assistance from an adult partner is needed for this assembly process.

During this assembly process - do exercise caution. You may need to use your hand to press

down and or pave away the padded surface to facilitate the 'slip and slide' assembly.

Caution: Ensure that your fingers do not get caught or pinched in the assembly process.

Step 2




Turn the sofa upright and push the Sofa Backrest (B) downwards until it is fully slotted and locked into position in the Arm Planes.

Fully locked postion: Check and assess that the Arm Planes(C&D) and Sofa backrest (B) are

aligned and level.

Assistance from an adult partner is needed for this assembly process.




Tilt and lay the Sofa on its Sofa Backrest(B) onto a flat surface.

Push the Sofa Seat(A) downwards until it is fully slotted and locked into position in the Arm Panels(C&D).

Fully locked postion: Check and assess that the base of the Arm Panels(C&D) and Sofa Base(A) are aligned and level.

Assistance from an adult partner is needed for this assembly process.



Affix the Sofa Seat(A) to the Sofa Backrest(B) using Bolts(①), Spring

Washers(3), and Washers(2) with the Allen Wrench(4) as pictured above.

Then, attach the Sofa Seat(A) to the Left Arm Panel(D) and Right Arm Panel(C)

using Bolts(①), Spring Washers(③), and Washers(②) with the Allen Wrench(④) .


Tighten the Bolts fully in a sequential manner.

DO NOT fully tighten a Bolt in one go and then move on to the next.

Rather, In a sequential manner, gradually tighten each Bolt until all Bolts are evenly secured.

This methodology will ensure maximum evenness once all Bolts are fully tightened.

Note: If you can not insert the Bolts into position, please back to Step 3 to "push the Sofa Seat downwards".




Install the Middle Support Legs(E) with the Washer Ring(⑤) at the bottom of the sofa on the threaded stem.

Then insert the threaded stem into the threaded mounting postion as pictured above.

Tighten by turning the Leg clockwise.

Step 6



Your Sofa is ready for use.

This Sofa can only be used on a flat, level surface.

Care & Maintenance



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



Not for commercial use. For residential use only.



 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.