
























# ASSEMBLY INSTRUCTIONS






						
A   24PCS	B   30PCS	C   20PCS	D   24PCS	E   6PCS	F   6PCS	G   18PCS
						
H   10PCS	I   10PCS	J   36PCS	K   6PCS	L   36PCS	M   8PCS	N   4PCS
						
O   2PCS	P   2PCS	Q   2PCS	R   2PCS	S   2PCS	T   2PCS	U   2PCS






x2



# 1





# 2




# 3




# 4




5




6




7



8




9




x2


10




Adjust Right or Left







Adjust Up or Down



Adjust Forward or Back



# 11



# x2

# 12

