



CARE AND MAINTENANCE

Always turn the heater OFF and unplug the power cord from the outlet before cleaning, changing the lightbulbs, or moving the stove. Failure to do so could result in electric shock, personal injury, or fire.

Never immerse in water or spray with water. Doing so could result in electric shock, personal injury, or fire.

CLEANING

Metal: Buff using a soft cloth, slightly dampened with a citrus oil-based product. DO NOT use brass polish or household cleaners as these will damage the metal.

Glass: Use glass cleaner and dry thoroughly with a paper towel or lint-free cloth. NEVER use an abrasive cleaner or any cleaner that could scratch the surface.

Plastic: Wipe with a slightly damp cloth and a mild solution of dish soap and warm water.

Vents: Use a vacuum or duster to remove dust and dirt from the heater and vent areas.