


# Tilting Front Install TV WALL MOUNT

## Master<sup>TM</sup> Mounts



Model  
444T-L

**VESA PATTERNS**  
75x75, 100x100, 200x100,  
300x300 400x200, 400x400

Recommended for TVs up to 55+ inches  
TV weight must not exceed the  
Maximum capacity of 66 lbs

**NOTE:** Read the entire instruction manual before you start the installation and assembly of this mount.

 **WARNING**

Do not begin the installation until you have read and understand all the instructions and warnings included in this installation manual. If you have any questions regarding any of the instructions or warnings, please contact a professional or the product's distributor.

This mounting bracket was designed to be installed and utilized **ONLY** as specified in this manual. Improper installation of this product may cause damage and/or serious injury.

This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.

Make sure that the supporting surface and substructure will safely support the combined weight of the equipment and all the attached hardware and components.

If mounting to wood stud walls, make sure that the mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.

Always use an assistant or mechanical lifting equipment to safely lift and position the equipment/TV.


Tighten the screws firmly, but do not over tighten. Over tightening can cause damage to the screws and this greatly reduces their holding power.

This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury. Always consult with a professional or expert if you would like to use outdoors. The environment as well as many other conditions will have to be considered and installation is based solely on the experts warranties and claims.

# Component Checklist

**Important:**

Make sure that you have received all the parts according to the component checklist prior to installation. If any parts are missing or defective, call your local distributor for a replacement.



You will not be using all the screws/parts included in this mounting hardware kit. The hardware you will use is dependant on the TV and the conditions of where the TV will be installed/mounted.

## Package M



M5x14 (x4)  
M-A



M6x14E(x4)  
M-B



M8x20 (x4)  
M-C



M6x30 (x4)  
M-D



M8x30 (x4)  
M-E



Washer D5 (x4)  
M-F



Washer D8 (x4)  
M-G



Small Spacer (x8)  
M-H



Big Spacer (x4)  
M-I


## Package W



ST6.3x55 (x2)  
W-A




Concrete Anchor (x2)  
W-B




D6 Washer (x2)  
W-C



# Pull Cord To Separate the TV Plate from the Wall Mount Bracket





## 1a. For Wood Stud Mounting



1. Using the Wall Bracket, find and mark the exact location of the mounting holes.



2. Drill pilot holes.



3. Screw the Wall Bracket (T) onto the wall using Screws W-A (x2) and Washers W-C (x2) from the hardware kit.



Tighten until snug, do not over tighten.

Make sure that mounting screws are anchored into the center of each stud. The use of a stud finder is highly recommended.


Installers are responsible to provide hardware for other types of mounting situations in different environments.

Installers must verify that the supporting surface and substructure will safely support the combined weight of the equipment and all the attached hardware and components.




## 1b. For Solid Brick and Concrete Mounting



1. Using the Wall Bracket, find and mark the exact location of the mounting holes



2. Drill pilot holes




3. Screw the Wall Bracket (T) onto the wall using Screws W-A (x2) and Washers W-C (x2) from the hardware kit. Tighten until snug, do not over tighten.

## 2. Configuring the TV's VESA Pattern to Match Your TV

1. On the back of the TV are four threaded holes arranged in a rectangular/square pattern. You will use these holes to attach the TV to your mount.

2. Arrange the Extension Arms so the hole pattern matches your TV's. The most popular patterns are shown in the drawings.

3. Attach the Extension Arms to the TV Plate using the screws (D x8). Make sure to use 2 screws (D) in each Extension Arm.




### Warning!

Installers must verify the supporting surface and the substructure will safely support the combination of the equipment and all the attached hardware and components.

### 3-1. Attaching TV Plate to the TV for Flat Back TVs


Using the hardware shown in the illustration, attach the TV arms onto the TV using the TV's threaded VESA holes. Tighten screws until snug, do not over tighten.




### 3-2. Attaching TV Plate to the TV for Curved or Recessed Backs




Use small or big spacers between the TV Mount Plate (A) and the back of the TV so there is no space between the plate and the TV's back. You may stack and use multiple spacers for each screw.



## 4. Hanging the TV onto Wall Bracket



It is safest to have two people lift and hang the TV onto the mount.




Lift the TV with TV Plate attached up to the Wall Bracket (T) so that the hooks on the TV Plate (A) hang over the already installed Wall Bracket.

Before you let go of the TV, make certain that the TV Plate is securely attached to the Wall Bracket.


## 5. Adjusting the Tilt and Tension Bolts

Use Wrench (F) to adjust the tension of the two bolts on the top of the TV Plate for lateral movement. Loosen them slightly so you can make final adjustments to be sure your TV is perfectly level. Then tighten until snug.



+5°  
-12° Tilt

Use Wrench (E) to adjust the tension of the Allen Head Screws on the Wall Bracket. Adjust the tension to the degree you would like the TV to tilt. At a minimum, the screws should be snug.



**Congratulations!**  
You're going to love using this mount!



**CAUTION: DO NOT EXCEED  
RATED LISTED WEIGHT. SERIOUS  
INJURY OR PROPERTY DAMAGE  
MAY OCCUR!**



Master Mounts.com 800-423-5487  
Minneapolis MN USA