

TIME & TIDE CLOCK INSTRUCTIONS



To set your Time & Tide clock:

1. Adjust the hour and minute hands to your correct local time using the adjustment wheel on the back of the clock above the battery compartment.
2. Use the Tide Time set wheel to align the BLUE tide hand according to your local tide information. Engage a small screw driver or rod with ribs on moulded wheel below the battery compartment to rotate the setting wheel. This will move the blue tide hand around the Tide Dial sector
3. For best results set the Tide hand to "high tide" during a full moon or new moon phase.

