




8-Panel Set: Parts List & Shape Overview



Placement Verify the accessories match your model.
Examples: Use this list to confirm nothing is missing.



10-Panel Set: Parts List & Shape Overview




Placement Verify the accessories match your model.
Examples: Use this list to confirm nothing is missing.




Fence Installation Steps

Step 1 Link connector "F" and link "G" using stick "H".




Step 2 Assemble the fence using the link pieces.




This small dot helps keep it in place. Press down and push inward to secure it.
To remove, simply press down and pull outward.

Step 3 After unfolding, first install the top and bottom plastic parts, then install the second part, then the third piece, and continue in order.


Step 3a: Two pieces



Step 3b: Three pieces



Continue connecting the next playpen panel using connectors. Make sure the two adjacent connectors are installed in opposite directions.




IMPORTANT NOTE:

FOR FOLDING INSTALLATION


To fold the playpen for storage, install connectors on opposite sides: one inward, one outward (see diagram).

Step 4 Use connectors to join all fence panels.



Repeat until all panels are connected.

Fence Disassembly Steps



1. Press the white spring buckle.
2. Pull the panel and connector outwards to separate them.

Inward/Outward Opening Doors




Latch engagement: when door is closed.



Caution: The door can open inwards or outwards, but the opening angle should not exceed 90 degrees. Otherwise, the connector may be damaged.

Latch engagement: when door is open and in use





WARNING:

Children have died or been seriously injured when gate/enclosure is not securely installed.

MUST install wall cups to keep gate/enclosure in place.

Without them, child can push out and escape.

- Always install using all required parts.
- Use only with locking mechanism securely engaged.
- Install with this side away from child.
- Stop using when child can climb over or dislodge gate/enclosure.
- DO NOT use to prevent access to pools, spas, or other bodies of water.
- Adult assembly required