




Furniture-Style Dog Crate L Size



Exploded Drawing



Product Parts


A



B




C



D




E



F




G



H




I



J



K



2 pcs

L




2 pcs

M




2 pcs

N



2 pcs

O



2 pcs


Hardware

1



46 pcs

2



2 sets

3



24 pcs

4




46 pcs

5



22 pcs

6




3 pcs

7



6 pcs

8



2 sets

9



1 pc

10



8 sets

11



2 pcs

12



2 pcs


13



1 set


Step 1

1 6 pcs




Step 2

1 16 pcs





Step 3

1  6 pcs




Step 4

2  2 sets **3**  12 pcs




Step 5

4 3 pcs 5 2 pcs




Step 6

4 3 pcs 5 2 pcs




Step 7

5 5 pcs



Step 8

5 5 pcs




Step 9

4



16 pcs



Step 10

6




2 pcs


7




4 pcs




Step 11

- 3  6 pcs
 8  1 set






Step 12

- 6  1 pc
 7  2 pcs




Step 13

- 3  6 pcs
 8  1 set




Step 14

- 5  4 pcs
 9  1 pc
 10  8 sets




Step 15

1 2 pcs 5 1 pc




Step 16

4 2 pcs




Step 17




Step 18


4  6 pcs 5  3 pcs



Step 19



Step 20




X2

Step 21

4



8 pcs




Step 22


4




8 pcs



Step 23



Step 24



WALL MOUNTING ASSEMBLY

For added safety and stability, it is recommended that the wall mounting hardware be installed. For safe mounting, it is essential to use wall anchors appropriate to your wall type (i.e. plaster, drywall, concrete, etc.). Mount to wood studs whenever possible.

Use a 1/4"(6.5mm) drill bit to pilot the hole. If mounting to plaster, wood panels, brick or other drywall please consult a qualified professional.

Please make sure you use the right hardware for your wall type for your safety.

⚠ WARNING:
Do not install on a wall where items can fall off and injure a child.

⚠ WARNING:
CHOKING HAZARD, Unassembled parts may be choking hazard to children 3 years and younger.

⚠ CAUTION:
Adult assembly required.
Hardware contains small screws with sharp points.
Keep unassembled parts out of reach of small children.

Hardware

A. Screw x 1
M4x16mm



B. Small Washer x 2
Φ10XΦ5X1mm




C. Plastic Anchor x 1



D. Plastic Anchor x 1



The following tools (not included) are required for assembly:



Electric Drill

E. Wood Screw x 1
Φ4X32mm



F. Nut x1



G. Large washer x1
Φ16XΦ6X1mm



Wrench x1



1/4" (6.5mm) Drill Bit




Phillips® Screwdriver

Step 1

Attach Plastic strip to back of product.

Hole predrilled in product backboard #1




Step 2

Use 1/4" (6.5mm) drill bit to drill hole in wall

Do not drill an oversized hole or the wall anchor will not hold tightly into the wall.

Tap wall anchor into hole.

Secure product to wall with screw "E" through Plastic strap and into wall anchor.



Warning:

Serious or fatal injuries can occur from furniture tip-over. To help prevent furniture tip-over:

Use provided mounting hardware to secure furniture to the wall.

This may reduce but not eliminate the risk of furniture tip-over.

Do not allow children to climb on furniture.

Keep remote controls, toys, and other items that might attract children off of this product.

Unless specifically designed to accommodate, do not set televisions or other heavy objects on top of this product.