



ASSEMBLY INSTRUCTIONS

Parts List			
Pieces	Schema	Description	QTY
A	 (M8*45)	Screw	4
B	 (M8)	Flat washer	8
C	 (M8)	Lock washer	4
D	 (M8)	Nut	4
E		Nut cap	4
G		Wrench	1
H		Adjustable Foot	Factory already assembled
I		Seat	1
J		Base	1



WARNING!

- This chair has a 250 lbs weight capacity.
- Hang cushion over chair frame to dry if it gets wet to prevent mold/mildew.

ATTENTION:

1. Please read these instructions carefully before assembly.
2. Aluminum is soft metal over tighten may strip threads or break the part.
3. DO NOT use power tools.
4. Check parts against the parts list to make sure you have all parts needed for proper assembly.
5. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.



H: This part have been assembled by factory already.

1. Place the base on a flat, solid surface. Loosely attach the seat to the base. Please using screws(A), flat washers(B), lock washers(C), nuts(D) and nut caps(E).
 2. Tighten all the bolts and nuts completely. Use the adjuster feet to level the legs.
- Warning: DO NOT use acid or alkaline washing liquid to clean the product.

*** DO NOT OVER TIGHTEN**

*** NO SOCKET DRIVERS**



Made in China

*** NO POWER TOOLS**

