((goodvibesleep))

Adjustable Base Quick Start Guide

Flex King/Standard King (2x Twin XL)









Scan for a fast assembly video.


1 Unfold base on the ground facing upside down.




2 Untile twist ties and take out 2 bags and 1 box that are fastened to the frame.




3 Cut cable ties (x2) holding the base to Flex Headboards.




4 Screw in legs (x6).




Flip over onto legs, take care to hold the headboard since it is now loose from the frame. Plug base into power.




6 Insert Mattress Bar.




7 Repeat steps 1-6 to assemble second Twin XL, place side by side once assembled.




8 On the underside of each of the bases connect the Sync cord into the Sync boxes.




9 Use one of the two remotes and press the head up button. If both heads rise, the base is in Standard Queen Mode. If only one rises, the base is in Flex-Head Mode.




To Toggle between Flex-Head Mode and Standard Mode, press and hold both the "Anti-Snore" & "Zero Gravity" simultaneously on the remote until you hear one or two beeps. One beep means you are in Flex-head mode, two beeps means you are in Standard Mode.



To connect to bluetooth, press the bluetooth button. Base will say, "bluetooth on." To connect phone, tablet, or tv; turn bluetooth on on the device. Find "GVS_N#####" in your bluetooth settings. Base will say, "bluetooth connected when it's paired.



12 If you have x2 Twin XL bases to support a King bed, be sure to pair the speakers of each base together. Start by making sure one base is connected to a device through bluetooth. Then to pair the speakers together press and hold the "volume up" and "volume down" buttons simultaneously for about 5 seconds. The backlight will blink and the base will say, "pairing successful."



13 Press vibration button to adjust intensity of acoustic massage, the base has 3 different vibration intensities. Audio volume and vibration intensity can be adjusted separately using the remote.

