

















Assembly Instructions




Parts List


A  M3.0x16 14PC	B  M3.5x25 12PC	C  M3.5x35 30PC	D  M3.5x50 8PC	E  2PC
F  8PC	1  1PC	2  1PC	3  1PC	4  1PC
5  1PC	6  2PC	7  2PC	8  1PC	9  1PC
10  2PC	11  2PC	12  2PC	13  2PC	14  2PC

Assembly Guide


STEP 1





STEP 2




STEP 3




STEP 4




STEP 5




M3.5x25
8PC




STEP 6




M3.5x25
4PC




STEP 7





STEP 8




STEP 9







STEP 10



M3.0x16
6PC





STEP 11




M3.5x35
1PC


M3.5x50
4PC




STEP 12







STEP 13




STEP 14




STEP 15



M3.5x50
4PC



STEP 16



STEP 17

