

USER MANUAL

Thank you support!

Thank you for choosing our collapsible wagon.
We hope it brings you lasting convenience and reliability.

Should you have any questions, need assistance,
please do not hesitate to contact us through your Amazon order page.
We are always here to help and value your satisfaction.
Enjoy your new wagon!



WARNING

Immediate Discontinuation: Discontinue use immediately if any defect is found.

Personal Safety: Wear gloves during assembly, installation, or disassembly to protect against moving parts.

Intended Use: This wagon is designed for cargo transport only. It must never be used to transport children or adults under any circumstances.

Load & Environment: Always stay within the recommended weight capacity to ensure safety and prevent product failure. Avoid prolonged exposure to direct sunlight, water, or moisture. If the wagon gets wet, dry it thoroughly immediately.

Proper Handling: For optimal performance and durability, use on level ground with secure footing and avoid rough, uneven, or icy terrain. Assemble and fold with care, avoiding excessive force to prevent damage. A slight odor from the tires upon unboxing is normal and harmless.

1. Parts Checklist ●●●



Wagon
(with Replaceable Cover) x 1



Removable Handle x 1



Detachable Wheels x 4
(2 Front, 2 Rear)

2. Assembly&Use ●●●

Step 1: Install Wheels



When installing the front wheels, press the button and push inward to install.



For the rear wheels, align the holes, gently press the button, and push inward.




Step 2: Expand The Frame



Pull the wagon frame to both sides until it locks in place.

Step 3: Install the handle



Align the holes on the tube, press the button, and push the handle in to secure it.


1

Step 4: Use Handle



Pull the handle upward to extend it to your desired length for use.

Step 5:



Peel off the Velcro and unzip the fabric —it transforms into a stylish beach chair! Enjoy your relaxing time.

3. Storage Instructions ●●●



1. Lift the base handle and fold/collapse the wagon completely.



2. Align the holes on the tube, press the button, and pull the handle out to remove it.



3. Put the removed wheels into the mesh pocket. Storage complete — well done!

2