


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

No Tools Required For Assembly

EASY ●●○○○ DIFFICULT




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES




1 When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2 Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3 Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4 Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5 Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



6 Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.












Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.





MD


Parts List


-  #1 x 1pc
Left Loveseat
-  #2 x 1pc
Right Loveseat
-  #3 x 1pc
Left armrest
-  #4 x 1pc
Right armrest
-  #5 x 1pc
Left seat cushion
-  #6 x 1pc
Right seat cushion
-  #7 x 2pcs
Pillow
-  #8 x 2pcs
Waist pillow

-  #9 x 1pc
Ottoman

Hardware List



-  #A x 8pcs
Sofa Leg
-  #B x 2pcs
Middle leg
-  #C x 14pcs
Plastic washer
-  #D X 4pcs
Ottoman Leg









1) Take legs out of bottom compartments of left loveseat (#1). Place a plastic washer (#C) to each legs (#A), then attach legs (#A) to the left loveseat (#1) and armrest (#3).

2) Slide left loveseat (#1) through the slider of left armrest (#3) until secured.





Place left seat cushion (#5), then pillows (#7,8) onto the left loveseat (#1).







1) Take legs out of bottom compartments of right loveseat (#2). Place a plastic washer (#C) to each legs (#A), then attach legs (#A) to the right loveseat (#2) and armrest (#4).

2) Slide right loveseat (#2) through the sliders of right armrest (#4) until secured.




Place right seat cushion (#6), then pillows (#7,8) onto right loveseat (#2).







Take legs out of bottom compartments of ottoman (#9). Place a plastic washer (#C) to each legs (#D), then attach legs (#D) to the ottoman (#9).





Slide the left and right loveseats together through the connectors.
Make sure it is secured together.



ASSEMBLY IS COMPLETED