

ASSEMBLY INSTRUCTIONS

Note:

Before assembling your new lamp, please read the following precautions and instructions thoroughly.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in polarized outlet one way only. If the plug does not fit fully in the outlet, please reverse the plug. If it still does not fit, contact a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.

The electrical wire is connected continuously through the poles, do not pull wire during unpacking, bad connections may result.

Place the lamp indoor dry area only. The lamp produces very high temperature, always unplug electrical cord and allow sufficient time for bulb to cool down before replacing bulb.

1. Carefully unpack all parts from the packaging and place them on a carpet/flat/smooth surface.

Be sure to remove all the packaging materials from the lamp.

* Do not plug into the electrical outlet when installing or replacing bulb.

2. Screw the **Steel Pipe** onto the **Base** with the **Screw(A)**, **Spring washer** and **Washer**.

(**Spring Washer, Washer and Screw A** are pre-installed at end of pole)

3. Screw tightly the above steps with the provided **Allen Wrench**.

4. Link up the Male and Female **Connector** together.

5. Insert the **5 Arch Pipe** into the **Steel Pipe**, push down hard and secure it with **Screw B**.

(if the predrilled hole is not aligned, it is okay to use a half inch nail and hammer to drill another hole)

6. Unscrew **Ring Caps** from the **Socket**, and place the **Shades** onto the tips of the **5 Arch Pipe** through the **Light Bulb Socket**.

7. Screw the **Ring Caps** onto the **Light Bulb Socket** through the **Shades** tightly.

8. Place the **Bulbs** onto the **Light Bulb Socket**. (Light Bulbs Included)

9. Insert the plug into the wall outlet, you are ready to use.

WARNING: For your long-lasting uses, please use approved Dimmable LED Bulbs only.

Light bulb item #: L2A-4TDM-E12-27. Other brand may not be compatible to our LED lamp, it may cause the dimmer switch to burn out quickly, therefore void the manufacture warranty that comes with this lamp.

Please note: Because of the LED technology, it's normal to experience some flickering in LOW dim level. As time progress, new LED technology will overcome this issue.

