


STUDIO | A HOME

A GLOBAL VIEWS COMPANY

7.90651 & 7.90652 - Teton Console



Step 1 - Unpack all parts and lay them aside.

Step 2 - Place base of console on desired spot of wall

Step 3 - Make sure the back and middle section of console are flush against the wall

Step 4 - Use a level to be sure the top and sides of the console are level

Step 5 - Screw the console to the wall using three or more screws in the designated area - rectangle below the frame on the base

Step 6 - Check that the base is level and stable against the wall

Step 7 - Place stone top onto the base of the console

*Hardware Not Included