









Assembly Instruction

							
Chair base	Backrest	Connecting pole	Power cord	Remote control	Power source	Armpad	Anti-fall bracket*2

STEP1




Diagram showing the connecting poles (C) being inserted into the chair base (A) and the armpad (G) being attached to the base.

STEP2




Diagram showing the armpad (G) being attached to the chair base (A). A circular inset shows the front view of the armpad being plugged straight into the front end of the jack.

Front
Plug it straight in at the front end of the jack

STEP3




Diagram showing the chair back (B) being inserted into the chair base (A). A circular inset shows the backrest being inserted into the base, with a green checkmark indicating correct alignment and a red X indicating incorrect alignment. The text below the inset reads: "Insert chair back to the chair base, make sure the slots on the back fully aligned to the bottom part".

Before use, please connect the controller first and then the power plug. Gently press the power switch to start working. When stopping use, simply press the power switch.

If the manual control does not work during use, please stop using it immediately. At the same time, first disconnect the power supply, unplug the power connector, and then unplug the manual controller connector. Then connect the manual controller connector in sequence and connect the power plug to test whether the function returns to normal. If the above operations fail to make the product work properly, please immediately stop using and contact the seller;

Note: When this product is not in use for a long time, please cut off the power supply!


Assembly Instruction

STEP4

- No.1 and No.2 wire connect with the backrest and chair base.
- No.3 wire connects with backrest and power cord(D).
- No.4 wire connects with backrest and remote control(E).
- No.5 wire connect the motor and the wire from rightside armrest, which use to connect the control panel.
- No.6 wire connect the motor and power source (F).
- NO.7 power cord for USB & Type-c



NOTE

- 1: Two same color wires connect.
- 2: Plug power cord and power source into outlet, then you can use all function.






Assembly Instruction

How to recline?




How to get footrest latch down and stand?



Assembly Instruction

How to use remote control?



How to use control panel that outside of right armrest?

Control panel is for chair lift and reclining function, also has dual USB outlets (5V2A+Type C) that keep your devices charging, such as nearly all smartphone(like iPhone, Samsung..), ipad, headphones, Kindle...

