
USER MANUAL

3 Doors Shoe Cabinet Assembly Instruction



General Assembly Guidelines


I. Ensure that all parts and hardware are available before beginning assembly.

II. Follow each step carefully to ensure the proper assembly of this product.


III. Two people are recommended for ease in the assembly of this product.

IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.


V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



VI. A Phillips head screwdriver is required for the assembly of this product.




VII. Power tools should not be used to assemble this product.




VIII. Drill may be needed for securing product to wall.


IX. Concealed hinges are three-way adjustable.




Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm mounting screw or via cam adjustment



Vertical
Via slots in the mounting plate or via cam adjustment





A	x12
M6*35mm	

B	x12
ϕ15*10mm	

C	x12
M6*30mm	

D	x9
M4*35mm	

E	x36
M3.5*12mm	

F	x6

G	x6

H	x6

I	x6

J	x6
M4*10mm	

K	x3

L	x3

M	x6
M6*40mm	

N	x4

O	x2

P	x2

Q	x2

R	x3


S	x18


T	x12


U	x54
M4*12mm	

V	x1

1








G	x6




H	x6





A	x12





2




D	x3	C	x2
			

3







C	x3
	


B	x6
	


4



5







C	x3
	

B	x6
	


6




7




D	x4




C	x4




8






M	x6




V	x1




9







U	x6
	


10




x3

E	x30	F	x6	K	x3	L	x3	R	x3
									

11




x3

J	x6
	


I	x6
	


12



E	x6
	


13





T	x12
	

U	x48
	


14






S	x18
	


15












N	x4

O	x2

P	x2

D	x2

Q	x2



WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Des blessures graves ou mortelles peuvent survenir à la suite d'un basculement des meubles. Pour éviter que les meubles ne basculent, nous recommandons qu'ils ne sont fixés en permanence au mur. L'ancrage mural et le matériel sont inclus dans ce produit. Veuillez assurez-vous que le matériel est adapté à vos murs avant d'installer, car différents matériaux muraux peuvent nécessiter différents types d'ancres.

Pueden producirse lesiones graves o mortales al volcar los muebles. Para evitar que los muebles se vuelquen, recomendamos que se fijen permanentemente a la pared. El anclaje de pared y los herrajes están incluidos en este producto. Asegúrese de que los herrajes sean adecuados para sus paredes antes de instalarlos, ya que los diferentes materiales de las paredes pueden requerir diferentes tipos de anclajes.

Beim Umkippen von Möbeln können schwere oder tödliche Verletzungen auftreten. Um ein Umkippen der Möbel zu verhindern, empfehlen wir, diese dauerhaft an die Wand zu befestigen. Wandanker und Hardware sind mit diesem Produkt enthalten. Bitte stellen Sie vor der Installation sicher, dass die Hardware für Ihre Wände geeignet ist, da für unterschiedliche Wandmaterialien möglicherweise unterschiedliche Arten von Ankern erforderlich sind.

Wall



Final Assembly

