



OWNER MANUAL




Thank you for shopping with us!

We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.


Hardware

NO.	Draw	QTY	NO.	Draw	QTY
A	 Screws Ø4x14mm	44	I	 Hinges (Internal hiding)	4
B	 Two-in-one connector	17	J	 Handles	2
C	 Two-in-one connector	17	K	 Screws M4x22mm	4
D	 Wood plug	4	L	 Anti-collision gasket	4
E	 Plastic anchor(Ø10mm)	4	M	 Screwdriver	1
F	 Screws for fix on the wall	4			
G	 Bracket (53x70x44mm)	2			
H	 Bracket (19x19x35mm)	2			


Recommended tools





Dimensions





Components



Step 1




	x3
B	
	x3
C	
	x1
M	




Notes: Screw installation depth as shown


Attention: Cam lock arrow point to the steel rod.




Step 2




Note: The D parts are used for these two holes




	x3
B	
	x3
C	
	x2
D	
	x1
M	




first step




second step



third step




Step 3



	x4
B	
	x4
C	
	x1
M	



Step 4



	x7
B	
	x7
C	
	x2
D	
	x1
M	

Note: The D parts are used for these two holes

Step 5



x2

G

($\varnothing 4 \times 14\text{mm}$)




x12

A



Tool

Step 6



x2

H

($\varnothing 4 \times 14\text{mm}$)




x8

A




Tool

Step 7




	x4
I	
($\varnothing 4 \times 14\text{mm}$)	
	x24
A	
Tool	

You can adjust the doors by tightening or loosening the screws on the hinge. ➔




Step 8



	x2
J	
(M4 x22mm)	
	x4
K	
	x4
L	
M	

Step 9




Tool



+

+

+



Step 10




Tool




.

.


.




Step 11




Step 12




Step 13




Finished




Dimensions



Top View



Front View



Back View

CARE CLEANING AND MAINTENANCE

1. Dust regularly with a soft , dry cloth.
2. Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.
3. Excessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.
4. The sink top is resilient, but care needs to be taken to preserve its appearance.
5. Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.