



MINIMALIST FARMHOUSE DRESSER WITH 6 DRAWERS



USER MANUAL



Contents


TOPIC	PAGE
01	
SAFETY INSTRUCTIONS	01-01
1-1	Thank You For Choosing Our Product 01
1-2	Precautions 01
02	
INSTALLING MODULES	02-19
2-1	Disassembly Diagram 02
2-2	Parts List 03-04
2-3	Assembly Instructions 05-19
03	
CUSTOMER SERVICE	20
3-1	30-Day Return Policy 20
3-2	1-Year Warranty 20
3-3	Quick Response Within 24 Hours 20
04	
PROBLEMS YOU MAY ENCOUNTER	21
4-1	Problems You May Encounter 21

Safety Instructions

Thank You For Choosing Our Product

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included. Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


Precautions




- Avoid long-term direct sunlight exposure.



- Keep away from sharp objects.




- Keep away from heat.



- Keep infants/children away from assembly parts to avoid choking and suffocation.





- Keep away from corrosive substances.




- Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.


Disassembly Diagram



x6




Px3



















Qx3


















Parts List

For ease and safety, we recommend two people for assembly.



A x1 	B x1 	C x1 	D x2 
E x1 	F x1 	G x1 	H x1 
I x1 	J x2 	K x6 	L x6 
M x6 	N x6 	O x6 	P x3 
Q x3 			




Parts List

CL	CR	DL	DR
x6 	x6 	x6 	x6 
Note: Disassemble bundled rails and classify by code.			
① x36  3 Spares	② x29  Φ6x30 3 Spares	③ x56  M5x40 3 Spares	④ x36  3 Spares
⑤ x75  M3.5x12 3 Spares	⑥ x6  3 Spares	⑦ x14  M3.5x16.5 2 Spares	⑧ x1  3 Spares
⑨ x9  1 Spare	⑩ x9  M3x20 1 Spare	⑪ x1  3 Spares	⑫ x7  M5x12.5 1 Spare
⑬ x2  1 Spare	⑭ x1  3 Spares	⑮ x31  3 Spares	

Assembly Instructions

1



Before assembling the product, please pre-assemble accessories ①.
Please install each accessory correctly as shown in the diagram.




Assembly Instructions

2

Before assembling the product, please pre-assemble accessories ①. Pay attention to installation on both the front and back sides.




Both Sides






3

Before assembling the product, please pre-assemble accessories ②. Please install each accessory correctly as shown in the diagram.

x1




x6








Assembly Instructions

4

Install the drawer slides CL on A and CR on B.
Please pay attention to choosing the correct screw holes.



Please tighten the screws, or the guide rail will make noise.




A x1		B x1		CL x3		CR x3		5 x24		14 x1	
----------------	--	----------------	--	-----------------	--	-----------------	--	-----------------	--	-----------------	--




Assembly Instructions

5

Install slide rails on both the front and back sides of board E, with a total of six slide rails. Please pay attention to choosing the correct screw holes.



Please tighten the screws, or the guide rail will make noise.




E x1		CL x3		CR x3		5 x24		14 x1	
----------------	--	-----------------	--	-----------------	--	-----------------	--	-----------------	--

Assembly Instructions


6

Please install the drawer according to the steps shown in the picture. Please note that the groove tracks on K, L and M need to face inward and be aligned. Please pay attention to tightening the Cam Lock ④.


1





2




3




4



Press The Cam Lock



Tighten It Clockwise



Rotate to About 60%




Total 6 Pcs

K x6	L x6	M x6	N x6	O x6	P x3	Q x3
③ x36	④ x18	⑥ x6	⑦ x12	⑬ x1	⑭ x1	

Assembly Instructions


7

Install the drawer slides DL on K and DR on L.
Please pay attention to choosing the correct screw holes.



x6

DL		DR		(5)		(14)	
x6		x6		x24		x1	




Please tighten the screws, or the guide rail will make noise.

Assembly Instructions

8

Connect boards D and F respectively to board E.
Please pay attention to tightening the Cam Lock ④.




D		E		F		④		⑭	
x2		x1		x1		x5		x1	


Assembly Instructions

9


First, connect board B to D and F.
Then, connect H, I and G to B respectively.
Finally, fix G and E together with screw ③.
Please pay attention to tightening the Cam Lock ④.




Press The
Cam Lock



Tighten It
Clockwise



Rotate to
About 60%




③ x9		④ x2		⑬ x1		⑭ x1	
B x1		G x1		H x1		I x1	


Assembly Instructions

10

Install the board A.
Please pay attention to tightening the Cam Lock ④.




Press The
Cam Lock



Tighten It
Clockwise




Rotate to
About 60%



A x1		3 x8		4 x2		13 x1		14 x1	
----------------	--	----------------	--	----------------	--	-----------------	--	-----------------	--

Assembly Instructions

11 Install part 11.







11 x1		12 x6		14 x1	
-----------------	--	-----------------	--	-----------------	--


Assembly Instructions

12

Slowly push board J down along the groove tracks on A and B to the end. Part 8 and the second board J are mounted in the same way as the first board J.




The board J must be fully inserted into the slot of the board G



Assembly Instructions


13

Install the board C.
Please pay attention to tightening the Cam Lock ④.



14

Install panel fastener.









9 x8		10 x8		14 x1	
---------	--	----------	--	----------	--

Assembly Instructions

15



Install the drawers into the cabinet as shown in the picture. Please note that drawer P is on the left and drawer Q is on the right. Incorrect placement will cause the drawer to fail to open and close properly.



Assembly Instructions

16

Cover the screw holes.





30 DAY Return Policy

If you're not completely satisfied with your purchase, please return the merchandise via our Official Customer Support. Unused merchandise can be refunded or exchanged within 30 days of purchase.



1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Having issue(s) while reading the instruction or completing the assembly.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of somescrew holes.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The screw holes that on the board and the steel frame don't line up.	1. Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjusting board and steel frame until the screw holes are lined up, then tighten all the screws.
	The board is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the desktops are flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Steel Frame	The steel frame is bent, broken, painted, rusted or damaged.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The table is unstable after being assembled.	1. Check if the screws are tightened. 2. Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3. If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.

We are committed to providing our customers with premium quality products and convenient customer service.

MADE IN MALAYSIA