



















Shoes Organizer Boxes Installation Instruction



The picture on the left is Blank Bottom
Panel and the picture on the right is the Top Panel which has a Pattern design.



Install the Clear Side Panel on each side of the Blank Bottom Panel. (The Raise Pattern Design side should point towards the inside of the Blank Bottom Panel)



Install the Top Panel with Pattern Design. (The Bottom Panel with " 前" and Top Panel with '前' should be aligned)



Install the Back Panel



Install the Front Panel Frame (The Downside with Screws)



Install the Clear Acrylic Window (The Magnets need to be aligned with the Screws on the bottom of Front Panel Frame)



Get Your Shoes Well Organized Instantly