

ASSEMBLY INSTRUCTION

PARTS LIST

1.-1PC 	2.-2PCS 	3.-2PCS 	4.-8PCS 	5.-4PCS
-------------------	--------------------	--------------------	--------------------	--------------------

FITTINGS

A.M8-4PCS 	B.M8-4PCS 	C.M8-4PCS 	D.Ø38-20PCS 	E.M8-4PCS 	F.M8-1PC
----------------------	----------------------	----------------------	------------------------	----------------------	---------------------

