


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED

Allen Wrench

(Included)




**Phillips
Screwdriver**

(Not Included)



**Rubber
Mallet**

(Not Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SIDE CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc



Back Rest

#4 1pc




Left Leg

#2 1pc



Seater

#5 1pc



Right Leg

#3 2pcs



Rail Support


#6 2pcs



Back Support

HARDWARE

#A 4pcs



Bolt M6 x 25mm

#B 4pcs



Bolt M6 x 50mm

#C 4pcs



Lock Washer M6

#D 4pcs



Nylon Washer M6

#E 4pcs



Bolt M8 x 35mm

#F 4pcs




Lock Washer M8

#G 4pcs



Flat Washer M8

#H 10pcs



PVC Dowel M8 x 30mm

#I 4pcs



Screw M4 x 38mm

#J 4pcs




Wood Button

#K 1pc



Allen Wrench M4

#L 1pc




Allen Wrench M5

ASSEMBLY INSTRUCTIONS


1

Part #3 x2pcs
Part #4 x1pc
Part #5 x1pc
Hardware #H x10pcs



2


Part #3 x2pcs
Part #4 x1pc
Part #5 x1pc
Hardware #B x4pcs
Hardware #D x4pcs



ASSEMBLY INSTRUCTIONS

3

Part #2 x1pc
Hardware #I x4pcs




2. Align and fasten the Both Leg #4 & #5 to Seater #2 by using the CSK Screw #I and fully tighten with screwdriver (NOT INCLUDED).

1. Align and insert PVC Dowel #H to bottom of Seater #2.

4

Part #6 x2pcs
Hardware #E x4pcs
Hardware #F x4pcs
Hardware #G x4pcs




1. Align and fasten Back Support #6 to Seater #2 using Bolt #E and Lock Washer #F and Flat Washer #G and do not fully tighten with Allen Wrench #L.


ASSEMBLY INSTRUCTIONS

5

Part **#1** x1pc
Hardware **#A** x4pcs
Hardware **#C** x4pcs
Hardware **#J** x4pcs



1. Align and fasten Back Rest #1 to Back Support #6 using Bolt #A and Lock Washer #C and fully tighten with Allen Wrench #K. Insert Wood Button #J to cover the open hole of the Back Support #6 and light tap with rubber mallet (NOT INCLUDED). **Fully tighten all the bolt.**



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.