


# TABLE LAMP



## PLEASE READ AND SAVE THESE INSTRUCTIONS:

1. REMOVE ALL PARTS AND LAY ON A FLAT SURFACE.
2. ATTACH THE HARP(B) ON THE SOCKET(A).
3. SET THE SHADE(C) ON THE HARP(B) AND TIGHTEN CLOCKWISE WITH THE FINIAL(D).



## MAINTENANCE:

Please use a 60 watt incandescent bulb.

## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug ( one blade is wider than the other ) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. **Never** use with an extension cord unless plug can be fully inserted. **DO NOT ALTER PLUG.**

