

Assembly Instructions

PACKAGED


- | | |
|----------------------------|----------------------|
| (A) 1 - Table Top Assembly | (D) 8 - Lock Washers |
| (B) 4 - Legs | (E) 8 - Flat Washers |
| (C) 8 - Machine Screws | |

Read all instructions before starting assembly.

Step #1 Remove all the contents from the package checking that all of the components listed in "Packaged" are included. Prepare a flat, protected work surface where the product can be assembled.

Step #2 Place Table Top Assembly (A) upside down onto protected surface. Make sure not to dislodge drawer. Align Leg (B) into apron notch of Table Top making sure the threaded insert of the Leg match up with the holes of the apron block. Attach one Lock Washer (D) and one Flat Washer (E) onto one Machine Screw (C). Install Machine Screw with attached washers thru one of the mounting holes in the apron block and into the threaded insert of the Leg and loosely tighten. Repeat procedure for remaining Machine Screws and Legs. Securely* tighten all Machine Screws.

Step #3 Place the assembled Table into upright position.



(*) Caution: DO NOT OVERTIGHTEN.

In any correspondence regarding this product, please include the complete identification number located on the underside of the product.

We hope this Accent Table will be a useful and decorative addition to your home for years to come.