


ASSEMBLY INSTRUCTION

48" TV stand





THIS INSTRUCTION BOOKLET IS IMPORTANT. PLEASE READ CAREFULLY.
AND KEEP FOR FUTURE REFERENCE.

















Before You Start

-  Please read all instructions carefully.
-  Retain instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
-  Always place the product on a flat, steady and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.






PACKAGE CONTENT (A)		
CODR	DESCRIPTION	QTY
1	Countertop Board	1
2	Middle Partition	1
3	Upper Lateral Plate	2
4	Top Vertical	2
5	Laminates	1
6	Upper Back Panel	1
7	Middle rung	1
8	Side plate	2
9	Middle side plate	2
10	Middle front block	2
11	Movable Shelf	2
12	Side backplane	2
13	Door plank	2
14	Floor	1
15	Bottom front bar	1
16	Bottom back strip	1
17	Bottom left bar	1
18	Bottom right bar	1
19	Bottom middle strip	1
20	Middle back panel	1
21	Middle activity layer board	1

(A)  47X+1X	(B) Ø8x30mm  35X+1X	(C) Ø15  47X+1X	(D)  2X
(E) Ø5/32"×22mm  4X	(F)  4X	(G) ø3.9×15mm Silvery  24X+1X	(H)  12X
(I) Ø3.5x16mm  33X+1X	(J)  8X	(K) Ø1/4"×12mm  16X	(L)  2X
(M) Ø2.9x12mm  4X	(N)  6X	(O) ø3.9×15mm Black  24X+1X	(P)  24X
(Q)  2X+4X	(R)  2X+2X	(AZ)  1X	


Step 1

J		8
K		8




Step 2

K		8
---	---	---




Step 3

A		6
B		5




Step 4

C		6
---	---	---




Step 5

N		6
O		24




Step 6

A		8
B		8




Step 7

A		6
B		4



Step 8

C		6
---	---	---




Step 9

C



8




Step 10

A




11




Step 11

B		2
C		3




Step 12

B		8
C		8




Step 13

M		4
L		2




Step 14

A		4
C		4




Step 15

A		6
B		4
C		6





Step 16

A		6
---	---	---





Step 17

B		4
C		6




Step 18

H		12
P		24




Step 19




Step 20

I		31
---	---	----



Step 21


D		2
E		4
G		8
F		4



Step 22



Note: When installing the cabinet door, install the bottom hinge first, and then install the upper part of the hinge.

G		16
---	---	----








Step 23

Q		2
I		2
Q		2



Step 24

R		2
Q		2



Step 25

