



Warning!

1. Please check that all parts in good condition before using. Never use if there are any
2. Never set up or continue to use in any rain, wind or stormy conditions.
3. Please don't stand and step on the frame, joint or chair.
4. Avoid bending the frame or pinching your fingers or hands while opening or closing the frame.
5. Avoid setting up your Camping Chair on steep inclines or on uneven ground.
6. Keep the Camping Chair away from heat and flames at all times.
7. Max weight capacity:200KG

Cleaning!


If your chair material is dirty, you can wash it below 30°C water. Please do not bleach, do not tumble dry, do not iron and do not dry clean.




BEACH CHAIR WITH WAGON



Package Include



200MM
Rotation payment



250MM
Rotation payment



How to Install



Open the chair



expand state



Press the wheel cap wire and install it onto the wheel rod



The wheel rod passes through the back frame of the chair base



Install small plastic parts first Install the wheels again, with the side with the longer center installed inside



Install small plastic parts first Install the wheels again, regardless of the inside and outside



Finally, install the wheel cap on the outer side



Pay attention to installing the other side wheel and press it against the single side wheel rod



As shown in the figure

How to operate



Open the sunshade



Rotating button, fixing sunshade



Armrest 7th gear adjustment



Lying flat requires lowering the support rod



Sunvisor retracted



Pull up the front rod



Side latch stuck



Installing a mesh bag

How to Fold



Remove the net bag



Put it in the back pocket



Pulling out the plug



Arrow pointing inward
Fold inward



folding forming

