


ASSEMBLY INSTRUCTIONS


HYSC-018-YM

HYSC-018-HT




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2


















Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes







ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(I)		X1
(B)		X1	(J)		X2
(C)		X1	(K)		X1
(D)		X1	(L)		X1
(E)		X1	(M)		X1
(F)		X1	(N)		X1
(G)		X1	(O)		X1
(H)		X1			

ASSEMBLY INSTRUCTIONS

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	 Ø8*30mm	X24+2	8		X8
2		X20+2	9		X2
3		X20+2	10		X4
4	 Ø1/4"*1-1/4"	X8	11	 Ø3*14mm	X36+3
5		X8	12	 Ø3.5*25mm	X2
6		X8	13		X4
7	 Ø3*15mm	X23+2	14		X1
			15		X1

ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

1





① C 1PC



① D 1PC




② 4PCS




ASSEMBLY INSTRUCTIONS


2




⑤ 1PC



⑦ 1PC




③ 6PCS



① 6PCS




② 2PCS




ASSEMBLY INSTRUCTIONS

3



(A) 1PC




(N) 1PC




Ø3.5*25mm

(12) 2PCS




(3) 6PCS



(1) 6PCS






(2) 6PCS



ASSEMBLY INSTRUCTIONS

4




ASSEMBLY INSTRUCTIONS

5




② 8PCS




ASSEMBLY INSTRUCTIONS


6




① 1PC



③ 8PCS




① 8PCS




ASSEMBLY INSTRUCTIONS

7



⑦ 1PC





Ø3*15mm

⑦ 23PCS




⑧ 8PCS




ASSEMBLY INSTRUCTIONS


8



(H) 1PC



(I) 1PC



(K) 1PC



(10) 2PCS





Ø3*14mm



Ø10*3mm







(11) 4PCS

(13) 1PCS



ASSEMBLY INSTRUCTIONS

9




ASSEMBLY INSTRUCTIONS

10




Ø3*14mm

⑪ 24PCS



ASSEMBLY INSTRUCTIONS

11




①

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm




②

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm



③

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


12

Common Door Panel Issues:




ASSEMBLY INSTRUCTIONS

13




15 1set

A




1pcs

B




2pcs

C




Ø8*3/4"
1pcs

D



Ø8*1-1/2"
1pcs

E



1pcs

