ASSEMBLY INSTRUCTIONS 4 DRAWER DRESSING TABLE

IMPORTANT

READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR 4 DRAWER DRESSING TABLE.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH & SAFETY:

DO NOT use this item if any parts are missing, damaged or worn.

DO NOT use this item unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

It is recommended that two people handle and assemble the item.

CARE & MAINTENANCE:

Assemble in the room of use.

To avoid damages assemble the item on a soft, clean surface

Periodically check all screws & fixings to ensure they are secure.

DO NOT push the item as this will damage the base.

Always lift the item with two people to reposition.

Keep any sharp objects away from the item.

This product is manufactured in pine which is a wood with natural characteristics including knots, grains, clusters or indentations.


On unpacking the item you may notice an odour due to production processes but this will disappear after a period of time.

DO NOT place the item next to a radiator or direct sunlight – this item is susceptible to temperature change. It is recommended an even room temperature be maintained with no sudden fluctuations.

DO NOT place hot or cold items directly onto the surface of the item as marking will occur

For general cleaning use a duster or damp cloth (almost dry) not wet – do not use soap and water, detergents, aerosol sprays or any polish as use of these materials would invalidate any claims.


DO NOT place the item onto wet or damp flooring as staining may occur to the floor.





n == 00 1 1 13 1 10 10 10 10 10 10 10 10 10 10 10 10 1			
		5 Back panel (77.5 x 37.4	4
1 Top panel (100 x 45cm)		Back parier (77.5 x 37.2	+cm)
		[0 0	1 • •
	0	6 Right front frame (81	x 4.5cm)
	Тор	0 0	
		7 Left front frame (81 x 4	4.5cm)
	Q		
2 Right side panel (81 x 42cm)			
D	0 0	8 Middle front frame (8	1 x 4.5cm)
Top	(x		7
Top			
		9 Right front frame (52.3	3 x 9.2cm)
3 Left side panel (81 x 42cm)		D	9
0 0	Q	10 Right back rail (55 x 9.	2cm)
	•		
	Тор	11 Front plinth (43.2 x 9.2c	em)
. • • • •	°		
4 Middle panel (81 x 42cm)			
	•	18 Drawer bottom x 4	
	maller drawer front 29.6 x 11.2cm)	(30.6 x 28.2cm)	
12 Larger drawer front x 3 (29.6 x 19.5cm)	0 *	D 0	22 Drawer runner
	-	19 Left back rail (35.6 x 6.5cm)	x 8 (32 x 3.5cm)
	maller drawer sides 2 (32 x 11.2cm)		
13 Larger drawer sides		20 Left front frame	23 Smaller front plinth
x 6 (32 x 19.5cm)	maller drawer back	(30.2 x 6.5cm)	(6.6 x 9.2cm)
17 (2	7.2 x 11.2cm)		
		21 Side plinth x 3	24 Block x 6 (10 x 2cm)
Larger drawer back x 3 (27.2 x 19.5cm)		(42.8 x 9.2cm)	
			Page 2 of 11


HARDWARE LIST									
Part	Item		Qty	Part	ltem*	Qty			
Δ	Wooden dowel		46	9	Drawer handle	4			
₿	14mm Screw	(1) mm	1	G	Round metal stud	6			
Θ	30mm Screw		42	0	Nail 0	16			
0	35mm Screw	(I)—H0000	54	9	Washer	2			
(3	19mm Bolt		4	•	Wall strap	1			


You will need a small mallet and a screwdriver.

























Page 8 of 11




Step 14: b: [14] a: 13 18 **3**x Θ C: d: Step 15: Page 10 of 11





Step 17: The product should be fixed to the wall using the wall strap. The screw to affix to the wall not supplied with this product. Please use screw and fixing appropriate for the wall type. (If in doubt you should seek professional advice) Warning: Always ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.



Additional Information

If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues.

Page 11 of 11