


ASSEMBLY INSTRUCTIONS





WARNING !




Estimated Time for Assembly

45 mins


MAXIMUM LOAD
220 lb/ 100kg



MAXIMUM LOAD
20 lb/ 9.1kg



Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




① x1




② x1




③ x1




④ x1




⑤ x1




⑥ x1




⑦ x2




⑧ x2



⑨ x2
















⑩ x2



⑪ x2





HARDWARE LIST








For your best understanding, this AI is for 1 single product assembly with 1 set of accessory. However, if your purchase is duoble products, you will find 2 full sets of accessory inside the hardware package, with assemble instruction is the same.

Cam Lock Fastening System






Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 1






STEP 2






STEP 3






STEP 4




STEP 5






STEP 6



STEP 7





STEP 8




A x 4

STEP 9




	
Ø15x9.5	
B	x 4



STEP 10






	
Ø3.5x12	
D	x 2

	
E	x 1


STEP 11




STEP 12






STEP 13




STEP 14





STEP 15





STEP 16






STEP 17







STEP 18



STEP 19



Browse the bottom page of the LED instructions and scan the QR code with your phone. This way you can download and install the APP. You can control the switch of the light belt with your phone



FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly
- Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

- Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
- Small amount of mild soap can be used if necessary
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF and PB.

Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.

Make sure to dry the furniture immediately after cleaning