

# Important Pre-Assembly Instructions




1. Read this entire manual thoroughly before assembly and strictly follow all installation steps.
2. Check the outer carton for dents, cracks or impact damage right after receiving the goods.
3. If the packaging is intact, unpack all parts and confirm every component and hardware is complete, scratch-free and undamaged.


2







①Base×1



②Tabletop×1




③ Tabletop Mount Plate×1

| a ×1 | b ×10 | c ×10 | d x5 | e x6 |
|---|---|---|---|---|
|  |  |  |  |  |
| Hex Allen Wrench | Flat Head Screws | Flat Washers | Flat Head Screws | Leveling Foot Screws |

# Complete Parts & Hardware List

3




## Fasten Mount Plate to Top of Base


1. Place the Tabletop Mount Plate over the four threaded holes on the top of the base, align all holes precisely.
2. Take 4pcs screws, insert them through the plate from the top surface, only hand-fasten lightly for now.

**IMPORTANT WARNING: Do not fully tighten any screw at this stage. Loosely fit all four screws first to avoid the plate shifting out of alignment.**

3. After all four screws are loosely fixed, tighten them evenly and fully with the Hex Allen Wrench.

4






## Install Round Tabletop

**SAFETY REMINDER: The tabletop is heavy. Two people are required to lift and position it; do not install alone.**

1. With another person's help, lift the round tabletop and lay it evenly on the pre-assembled base.
2. Match the threaded holes on the tabletop's underside to the holes of the Tabletop Mount Plate.
3. Fit one flat washer onto each screw, then hand-thread all screws through the tabletop into the mount plate.
4. After all screws are loosely fitted, tighten each screw evenly one at a time with the Hex Allen Wrench to prevent an uneven table surface.


5



## Assembly Completed

1. Recheck all screws on the mount plate and tabletop to confirm all are fully tightened.
2. Shake the table gently from all sides to test stability; there must be no wobble or abnormal rattling noise.

6



## Leveling Foot Adjustment Guide

This adjustable leveling foot mounts on the bottom of the base to stabilize the table on uneven ground.
1. Screw the feet into the threaded holes at the column base.
2. Rotate the plastic foot to adjust height and stop table wobble.
Note: Installation is optional. The table works fine without these feet.