
ASSEMBLY INSTRUCTION

DINING TABLE



Please read these instructions fully before starting assembly：

1.Place all wooden parts on a clean and smooth surface such as arug or carpet to avoid scratching the parts.

2.Kindly follow the assembly instructions step by step.

3.Do not tighten all screws and bolts until the table is fully assembled.


4.Unscrew the protective plastique supports from the metal insert of the legs before assembly.


5. Parts of the assembly will be easier with 2 people.


Care and maintenance：


Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.






ASSEMBLY INSTRUCTION










Part List For One		Hardware List For One	
A 	TOP TABLE (1PC)	1  Ø5/16"x60mm	BOLT (12PCS)
B 	TABLE LEG (4PCS)	2  Ø5/16"x75mm	LONG BOLT (2PCS)
C 	STRETCHER (2PCS)	3  Ø5/16"x13mm	SPRING WASHER (14PCS)
D 	LONG STRETCHER (1PC)	4  Ø5/16"x19mm	FLAT WASHER (14PCS)
		5  M4	ALLEN KEY (1PC)


ASSEMBLY INSTRUCTION

STEP 1



2 Ø5/16"x75mm	LONG BOLT (2PCS)	3 Ø5/16"x13mm	SPRING WASHER (2PCS)
4 Ø5/16"x19mm	FLAT WASHER (2PCS)	5 M4	ALLEN KEY (1PC)

STEP 2



1 Ø5/16"x60mm	LONG BOLT (12PCS)	3 Ø5/16"x13mm	SPRING WASHER (12PCS)
4 Ø5/16"x19mm	FLAT WASHER (12PCS)	5 M4	ALLEN KEY (1PC)

ASSEMBLY INSTRUCTION

COMPLETE

