

## **DINING SIDE CHAIR**

---

### **ASSEMBLY INSTRUCTIONS**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### PARTS IDENTIFICATION

	PART NAME	FIGURE	QTY
A	BACK FRAME		1PC
B	FRONT LEG FRAME		1PC
C	SIDE RAIL		2PCS
D	SEAT CUSHION		1PC

### HARDWARE IDENTIFICATION


	HARDWARE NAME	FIGURE	QTY
1	ALLEN WRENCH (M4 x 110MM - BLK)		1PC
2	BOLT (M6 x 50MM - RBW)		6PCS
3	LOCK WASHER (1/4" - BLK)		6PCS
4	FLAT WASHER (M6 x 13MM - RBW)		6PCS
5	PAN HEAD SCREW (#8 x 1" - BLK)		4PCS

**NOTE : QUANTITIES SHOWN ARE FOR ONE CHAIR.**


**NOTE : PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS ; HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.**

# ASSEMBLY INSTRUCTIONS


## STEP 1



## STEP 2



## STEP 3



## STEP 4 Complete.

