

HOW TO SET UP AND CARE FOR VARSITY TROPHY DISPLAY CASES

ON ALL FREE STANDING (NON-WALL MOUNTED) CASES, INSTALL THE FURNITURE TIPPING RESTRAINT (HH500) PER INSTRUCTIONS LOCATED ON THE KIT'S PACKAGING.

1. Unpack case, shelves and hardware from skid.

FOR SLIDING DOOR VARSITY (#691 & #694)

2. Unpack doors from door wrap and install in case by lifting up into top track recess about 4" from left side. Move door in at bottom and lower edge of door into bottom track.
3. Clean thoroughly the glass area to receive door handles, placing them slightly below center, from top to bottom on left edge of inside door and right edge of outside door. Close each door fully into frame groove. Strip paper from handle and press handle firmly onto clean glass, using wood frame to align handle. To secure a good initial bond, open door and hold hand on inside face of glass behind handle pressing handle against glass with other hand.

FOR ALL VARSITY CASES:

4. Secure bracket in standard position in desired location and using one plastic shelf rest on each knife edge bracket to hold shelves turned wide face inward toward shelf center.
5. Level case in final position. Case is level when inside vertical edges of doors are parallel. Keep glass clean for best appearance.

On hinge door case, doors may be adjusted by loosening screws at hinges.