

ASSEMBLY INSTRUCTION


SKU# 97517

Before beginning


- Unpack all parts and hardware to ensure you have all needed components for assembly
- Read this guide cover before beginning assembly .
- Assemble this item on a soft surface such as carpet to protect finish.
- Proper assembly of this item requires 2 person & 20 minutes to assemble.

CARE INSTRUCTIONS


Wipe with a soft and dry cloth. To protect finish, avoid the use of chemicals and household cleaners. Any liquid in the table should be cleaned up immediately with a damp cloth.



BOX



LEG



C

HOW TO ASSEMBLE


- STEP-1 match marking C with C respectively.
- STEP-2 Insert allen bolt G then tighten with allen key E.
- STEP-3 Place the sideboard upside on rug and match marking A with A and B with B respectively.
- STEP-4 Insert allen bolt F with spring washer I and flat washer H then tighten with allen key D.
- STEP-5 Turn the sideboard upside down, sideboard ready to use.

No.	Sketch	Description.	Size (IN)	Qty.	Ext.
D		ALLEN KEY	0.19"	1	0
E		ALLEN KEY	0.15"	1	0
F		ALLEN BOLT	0.31X1"	08	1
G		ALLEN BOLT	0.23X0.78"	02	1
H		WASHER	0.35X1"	08	1
I		SPRING WASHER	0.35X1"	08	1
J		SCREWDRIVER		1	0



STEP- 1





Tip for leveling of product:
When the product rests on an uneven floor surface it will appear to be unbalanced. To aid in leveling, try adjusting the levelers on the bottom of each foot.




STEP- 2




STEP- 3



STEP- 4



STEP- 5



FINAL