

Installation & Assembly

- 1、 Install the armrest on the seat cushion
- 2、 Install the control mechanism on the seat cushion
- 3、 Connect the support to the backrest and Connect the backrest to the control mechanism
- 4、 Install the casters on the base
- 5、 Insert the air lift on the base