


CARRO

Humidifier

User Manual



Model Number: PH-305-20

Please read this instruction manual carefully before using the product.


1

Product Introduction

Parts and Installation Drawings

NOTE

All drawings in this manual are for interpretation only.
The appearance and functions of the product are in order to prevail in kind.



Parts List



User Manual*1



Power Cord*1

2

Instructions for Use

NOTE

- Be sure to unplug the power supply before adding water
- The height of water should not be higher than the water mist tube
- Do not pour water into the water mist tube
- Do not pour water into the base
- Do not unplug the power plug when hands are wet to avoid electric shock
- Do not add essential oils, perfumes, medicines, etc to the water.
- Clean tap water or pure water at temperatures below 104°F is applicable to the water tank

Installation Guide of Water Tank

Align the logo on the water tank with the knob on the base and vertically insert the tank into the base.




3

Instructions for Use

How to Add Water


NOTE: Remove the tape holding the float before first use.

- ① Take off the water tank cover
- ② Take off the water tank
- ③ Pour pure water into tank. DO not pour water into the water mist tube and base.



How to Add Essential Oil


- ① Take off the water tank
- ② Drop a few drops of essential oil into fragrance box
- ③ Install the water tank on the base



4

How to Control the Humidifier

NOTE



If the indoor temperature is too low or the humidity is too high, the water mist cannot be fully dispersed, please reduce the amount of water mist to save electricity.

1. When the knob is in "ON/OFF", the humidifier is in standby state.
2. Turn the knob clockwise can increase the amount of water mist. Turn the knob counterclockwise can reduce the amount of water mist.
3. Red indicator means the humidifier is in water shortage, please add water into the water tank. Blue indicator means humidifier is working properly.

Adjustable Water Mist's Direction



The direction of water mist can be adjusted by rotating the water tank cover. The cover can be rotated 360 degrees.

5

Safety Warnings and Cautions

NOTE

To reduce the risks of fault, electric shock, injury, fire, death, and equipment or property damage, please read this section carefully before using the humidifier.

The humidifier must be placed horizontally. If the humidifier is tilted, it may cause water to overflow from the water tank.

Prohibited Operation



- Do not plug or unplug the power cord with wet hands to avoid electric shock
- Do not turn on the machine when there is no water in the water tank or the water tank is separate from the base
- Do not add additives not produced or supervised by our company to the water tank
- Do not place anything in the water tank
- Do not replace the power cord without authorization or connect the power cord midway or use it in parallel with other electrical appliances
- Except professional repair technicians, please do not disassemble repair or modify the machine to avoid fire, electric shock, electric leakage and other dangers
- Do not directly shower the humidifier
- Keep the humidifier away from water, furniture, electrical appliance
- Do not stand or sit on the humidifier
- Do not turn off the humidifier by unplugging the power cord

6

- Please use clean tap water or pure water to humidify
- Do not use damaged or aged power cord. Please use the power cord configured by the company
- Power must be cut off during a thunderstorm, and hands must be kept dry when cut off
- When abnormal phenomena (such as burning smell) occur, you must power off and cut off the power supply
- When cleaning, maintaining, or moving the humidifier, shut it off and unplug the power plug
- To avoid bacterial growth, please replace the water in the tank regularly. Keep the tank in a steady state when adding water and Do not add water to the mist tube
- If the humidifier is toppled when there is water in the water tank, please power off immediately and unplug the power cable, and send it for maintenance
- Required Operational Environment: Temperature: 41°F - 104°F / Relative Humidity: < 80%RH
- Do not block the water mist outlet, please keep the water mist can be smoothly sprayed

7

Cleaning and Maintenance

NOTE

- Be sure to unplug the power supply before cleaning
- Be sure to clean the limescale and sundries in the water tank regularly. It is recommended to clean the water tank once every 2-3 weeks.

The Water Tank Cleaning

It is recommended to wipe the water tank with a clean, soft, damp cloth.



Clean Sink and Mistorizer

Add scale remover or water to clean, rinse after cleaning.



When not used for a long time:

1. Power off and unplug power cord
2. Empty the water tank and clean the water tank and base
3. Please pack the humidifier in a packing bag
4. Store the humidifier in an upright position in a dry and ventilated place

8

When used again after not used for a long time:

1. Remove the packing bag
2. Add appropriate water to the water tank after cleaning the tank and base
3. Plug in the power cord and turn on the power switch

Specifications

NOTE

- The following are the design parameters, and the actual parameters are subject to the product
- The amount of humidification varies with the indoor temperature and humidity

Model	PH-305-20
Rated Voltage	120V
Rated Frequency	60Hz
Rated Power	20W
Rated Water Tank Capacity	3.0L
Amount of Humidification	≥200mL/h
Noise	<38dB

9

Service Directory

Causes and Solutions of Common Problems

- If the humidifier does not work properly after the following operations, please contact the seller

Faults Phenomena	Cause Analysis	Solutions
The humidifier is not working	The power plug is not properly plugged in	Plug in properly
	There is no water in the tank	Add water into the water tank
	The water tank is not in place	Fasten the tank in place
The sprayed mist has an odor	The water is dirty or stored for a long time	Replace the clean water or clean the tank and sink
The humidification effect is not obvious	The air intake is blocked by dust	Remove dust from the air intake
Abnormal noise	The humidifier is tilted or unstable	Place on a firm surface or flat place to use
Water shortage alarm in full water state	The water level in the sink is judged to be too low because the humidifier is tilted at a certain Angle. Therefore, the humidifier automatically starts protection and shuts down	Keep the humidifier in a flat, firm place and steady



1YEARS product warranty
(If any quality problems are found, we will provide a free replacement)



Customer Support

10