













# ASSEMBLY INSTRUCTION


## TRESTLE GLASS TABLE

<b>A</b> Table Top  1 pc	<b>B</b> Leg  2 pcs	<b>C</b> Leg Frame  2 pcs	<b>D</b> Lower leg frame  1 pcs
<b>E</b> Screw Ø8x70mm  6 pcs	<b>F</b> Crescent spacer  6 pcs	<b>G</b> Flat Washer Ø9x19x1.5mm  6 pcs	<b>H</b> Nut  6 pcs
<b>I</b> Wrench  1 pcs	<b>J</b> Screwdriver  1 pcs	<b>K</b> Screw  14pcs	




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Attach the two legs (C) to the two legs (B). Use bolts (E), crescent-shaped spacers (F), and flat washers (G) on the holes in the leg rest (C). Screw the Allen wrench (H) into the Allen bolt (I).



- 2** Attach the lower tripod (C) to the foot (B). Use bolts (E), crescent-shaped spacers (F), and flat washers (G) on the holes in the leg rest (C). Screw the Allen wrench (I) into the Allen bolt (H).



- 3** Fix the tripod (B) (C) to the table top (A) with screws (K) and tighten it with a screwdriver (J).



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.