




ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



Allen Wrench

(Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

Check out our Quick Tips!


We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SOFA




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

#1 6pcs




ARMLESS CHAIR /CORNER BACK

#2 6pcs



BACK CUSHION

#3 3pcs



ADJUSTABLE ARM CUSHION

#4 1pc



ARMLESS CHAIR SEAT CUSHION

#5 1pc



RIGHT CHAIR SEAT CUSHION

#6 1pc



CONSOLE WITH STORAGE (WOODEN TOP)

#7 1pc



OTTOMAN

HARDWARE

#A 28pcs



SPACER

#B 28pcs



LEG

#C 28pcs


































SCREW

#D 7pcs



HEXAGON SPANNER

Points 7 cartons


Designation	Part		Hardware		
RIGHT CHAIR (ADJUSTABLE ARM CUSHION)	#1		#A		4pcs
	#2		#B		4pcs
	#5		#C		4pcs
			#D		1pc
CORNER	#1		#A		4pcs
	#2		#B		4pcs
	#4		#C		4pcs
			#D		1pc
ARMLESS CHAIR	#1		#A		4pcs
	#2		#B		4pcs
	#3		#C		4pcs
			#D		1pc
CONSOLE WITH STORAGE (WOODEN TOP)	#6		#A		4pcs
			#B		4pcs
			#C		4pcs
			#D		1pc
OTTOMAN	#7		#A		4pcs
			#B		4pcs
			#C		4pcs
			#D		1pc

ASSEMBLY INSTRUCTIONS

1

Part #1 x 3pcs

Part #3 x 3pcs



2


Part #2 x 3pcs

Hardware #A x 12pcs

Hardware #B x 12pcs

Hardware #C x 12pcs

Hardware #D x 1pc




ASSEMBLY INSTRUCTIONS

3

Part #1 x 2pcs

Part #4 x 1pc



4


Part #2 x 2pcs

Hardware #A x 4pcs

Hardware #B x 4pcs

Hardware #C x 4pcs

Hardware #D x 1pc




ASSEMBLY INSTRUCTIONS

555

Part #1 x 1pc

Part #5 x 1pc



6


Part #2 x 1pc

Hardware #A x 4pcs

Hardware #B x 4pcs

Hardware #C x 4pcs

Hardware #D x 1pc



ASSEMBLY INSTRUCTIONS

7



Part #6 x 1pc

Hardware #A x 4pcs

Hardware #B x 4pcs

Hardware #C x 4pcs

Hardware #D x 1pc



8



Part #7 x 1pc

Hardware #A x 4pcs

Hardware #B x 4pcs


Hardware #C x 4pcs

Hardware #D x 1pc




ASSEMBLY INSTRUCTIONS

9



10



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.