

Please read these instructions  
carefully before assembling.

## INSTRUCTION MANUAL

# PULSE REC CORNER DINING SET

---

## REC Corner Sofa


### Assembly Requirements:

Number of people required to assemble – 2

Approximate assembly time – 20 minutes

### Dimensions:

214\*260\*87cm



## COMPONENT PARTS

Please check if you have all the parts as listed below. Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


**A** SEAT BASE WITH 2 ARMS



**B** SEAT BASE WITH LEFT ARM




**C** LEG FRAMES BIGER SIZE



69CM LENGTH FOR 2 ARMS

**D** LEG FRAMES SMALLER SIZE



63CM LENGTH FOR LEFT ARM

**E** LEG BARS



**F** 1/4 X 55mm BOLTS



**G** WAHSERS  $\phi 6 \times \phi 18$



**H** ALLEN KEY




## ASSEMBLY INSTRUCTIONS

### STEP 1

For seat base with 2 arms:


Ensure all the parts are at the correct positions, using the allen key (Part H) to tighten up all the bolts.



## STEP 2


For seat base left arm:

Ensure all the parts are at the correct positions, using the allen key (Part H) to tighten up all the bolts.



## STEP 3

Carefully turn the assembled Sofas, and double check all the bolts are fully tightened.



## STEP 4

## Safety and Care Advice

### **KEEPING OOUTDOOR FABRIC LOOKING ITS BEST IS SIMPLE AND EASY.**

- Use a sponge or soft brush to apply mild soap and warm water to the fabric.
- Rinse thoroughly.
- Air dry.

### **FOR STUBBORN STAINS OR MILDEW:**

- Add one cup of bleach per gallon of soap and water.
- Apply directly to the stain.
- Use a sponge or soft brush to clean.
- Rinse thoroughly.
- Air dry.
- If necessary, repeat with additional bleach.

Always rinse thoroughly. Bleach won't harm the fabric, but it could damage clothing if not rinsed away.

All-Weather fabric air dries very quickly. Machine drying is unnecessary and high heat may damage the fabric.