

INSTALLATION
Product Manual

Version: 750025-01-26A-AA




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !


It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.


For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.



Please prepare the following tools
















When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

AC x 1	AD x 1	AE x 1	AF x 1
			
M4	M12	M5	M8



Please organize the removed panels and parts.






⚠WARNING

Children have died from furniture tipover.To reduce the risk of furniture tipover:


- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!



ASSEMBLED BY 2 ADULTS

1




2 OF ADULTS


Open the bed frame, then flip parts (19), (20) and (21) downward to unfold.

Note: Beware of pinching fingers.

2




To prevent the bed frame from bouncing back, place an object weighing more than 20 kg on it to hold it down.




2 OF ADULTS

3


Please remove part (Y) and place it in the storage box.
Remove the mattress.






2 OF ADULTS

4




Remove screws (E) and part (W-1) and place them in the storage box.




When moving the object, guard against the rebound of the bed frame.

5




Assemble assist panel 29.




Panel 24 is only used as an auxiliary plate, does not participate in cabinet assembly, and can be disposed of as you wish after use.

6

AC x 1




M4



Storage box


Auxiliary Panel 29 serves to support Panel 10 and 27.




Using the assembled assist panel (29) as support, remove screws (G) and Panels 10 and 27, then place screws (G) in the storage box.

7

AC x 1




M4






Auxiliary Panel 29 serves to support Panel 7 and 25.



Using the assembled assist panel (29) as support, remove screws (G) and Panels 7 and 25, then place screws (G) in the storage box.

8



Close the bed frame and push it toward the wall to a suitable distance. While closing the bed frame, fold parts (19), (20) and (21) upward to close.
Note: Beware of pinching fingers.




3 OF ADULTS

9

AF x 1

M8

Using part (AF), disconnect nuts (T) and part (R) from the connection end of part (13), then place nuts (T) in the storage box.




Storage box


3 OF ADULTS

10

Open the bed frame, then flip parts (19), (20) and (21) downward to unfold.


Note: Beware of pinching fingers.






2 OF ADULTS

11




Remove handles (U) and screws (V) and place them in the storage box.




12


AD x 1



Using part (AD), remove part (23) and place it in the storage box. **Note: Two or more people must work together to support the bed frame before removing part (23), to prevent the bed frame from falling after part (23) is removed.**




Storage box



2 OF ADULTS

13

After removing the bed frame from the main unit, fold parts (19) and (20) upward, and lift the bed frame to an open area.




14


AF x 1

M8


Using part (AF), remove nuts (T) and part (R) and place them in the storage box.




15

AE x 1	AF x 1	
 M5	 M8	


Using parts (AE) and (AF), remove screws (AJ), nuts (Q) and part (N), then place them in the storage box.




16

AC x 1	AF x 1	
 M4	 M8	

Using parts (AC) and (AF), remove screws (G), nuts (S), parts (19), (20) and (21), then place screws (G) and nuts (S) in the storage box.




Storage box




17

AC x 1




M4

Using part (AC), remove screws (L) and part (22), then place screws (L) in the storage box.




18


AC x 1




M4

Using part (AC), remove screws (G) and Panels 8, 9, 26 and 28 from the bed frame, then place screws (G) in the storage box.








2 OF ADULTS


19

AC x 1




M4

Using part (AC), remove screws (M) and part (15), then place screws (M) in the storage box.




20

AC x 1




M4


Using part (AC), remove screws (M) and part (14), then place screws (M) in the storage box.




21




First remove screws (AA) and part (Z), then remove screws (E) and part (W-2), and place them in the storage box.





22



Remove screws (E) and part (AH) and place them in the storage box.









23

Remove dowel pins (AK) and place them in the storage box.




If there is a keel inside the wall, please select Option A
If there is no keel inside the wall, please select Option B.


Option A



Option B




24





Option A

Remove the anti-tip device, then place screws (J) and screws (AL) in the storage box.





Option B






25






Remove screws (E) and part (X) and place them in the storage box.




Storage box

26




Remove the anti-tip device, then place screws (J) and screws (AL) in the storage box.



Option A


Option B



27


After removing the anti-tip device from the cabinet, place the cabinet in an open area and slowly tip it over.

Note: Once the anti-tip device has been removed, take care to prevent the cabinet from tipping over and causing injury.





28

AC x 1




M4






Storage box


Using part (AC), remove screws (P) and place them in the storage box.






29


AC x 1




M4




Remove screws (D) and dowel pins (C) and place them in the storage box.




Storage box






30


AC x 1




M4



Support Panels 2 and 5 with your hands while removing screws (D). Using part (AC), remove screws (P), then place dowel pins (C), screws (D) and screws (P) in the storage box.




Storage box




31


AC x 1




M4





Remove screws (D) and dowel pins (C). Using part (AC), remove screws (P) and place them in the storage box.




Storage box




32

B x 4	C x 4	
 CRB1595A	 CRF0830A	


Remove cam locks (B) and dowel pins (C) and place them in the storage box.



33




Remove self-tapping bolts (A) and place them in the storage box.




34


AC x 1



M4




Storage box




Using part (AC), remove screws (F) and part (11) from Panel 1, then place screws (F) in the storage box.

35

AC x 1




M4




Using part (AC), remove screws (AG) and Panel 24 from Panel 1, then place screws (AG) in the storage box.


36



Remove screws (AB) and part (13) and place them in the storage box.



Storage box



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT


adelahu@fufugaga.com


208-820-0068