




SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

	<p>A</p>  A1: 1.5 " 24PCS A2: 2.4 " 4PCS A3: 6.3 " 2PCS	<p>B</p>  4PCS						
	<p>C</p>  40PCS	<p>D</p>  16PCS						
<p>E</p>  4PCS	<p>F</p>  4PCS	<p>G</p>  20PCS	<p>H</p>  4PCS					
<p>I</p>  1PC	<p>J</p>  2PCS	<p>K</p>  2PCS	<p>L</p>  4PCS	 1PC		<p>M</p>  4PCS	 1PC	

Please unscrew all spare parts before assembling.
If you find the screw thread is rusty, please don't worry,
it will not affect the installation and use.

SKU: 6090-BS505BLK


ASSEMBLY INSTRUCTION



Decomposition Diagram


SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

STEP 1



2PCS


STEP 2




16pcs

SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

STEP 3




STEP 4




SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

STEP 5




STEP 6




SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

STEP 7




STEP 8




SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

STEP 9



STEP 10



SKU: 6090-BS505BLK
ASSEMBLY INSTRUCTION

STEP 11

