
INSTALLATION MANUAL

CHANDELIER

Model No.: XMP003BG-1A



Safety Rules

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS TURNED OFF. TURNING THE POWER OFF USING THE LIGHT SWITCH IS NOT SUFFICIENT TO PREVENT ELECTRICAL SHOCK.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions or situations that may occur. It must be understood that common sense, caution, and care, are factors which cannot be built into any product. These factors must be supplied by the person(s) installing this unit.

READ & SAVE THESE INSTRUCTIONS

CAUTION: Before assembling the lighting fixture, refer to the section titled Wiring Connections. If you feel you do not have enough electrical wiring experience, either refer to a do-it-yourself wiring handbook or have your lighting fixture installed by a qualified, licensed electrician.

INSTALLATION & OPERATION INSTRUCTIONS GENERAL

Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.


All electrical connections must be in accordance with local and National Electrical Code (NEC) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

Installation Preparation


Tools You Need




☑ Ladder




☑ Pliers




☑ Wire Strippers



☑ Screwdrivers



☐ Wrench



☐ Power Drill (optional)




☐ Drill Bit (optional)

What to Expect with your Installation




☑ Check the box to see the weight of the light



☑ Angled ceiling applicable

Packing List



Installation Kit

AA 3x Wire Nut	BB 2x Outlet Box Screw	CC 2x Wood Screw	DD 2x Washer
EE 2x Plastic Anchor	FF 1x Hex Wrench	GG 1x Gloves	


NOTE:
The listed quantity is for installation, extra hardware may be included.

Installation Instructions

1. Mount the Bracket (3 Options)


Option1. (For Outlet Box)


Secure the mounting bracket (A) to the outlet box with screws taken off from outlet box or screws (BB) and washers (DD) provided.



Option 2. (For Solid Wood Structure)


Mark and drill the screw holes on the solid wood structure.
Mount the mounting bracket with screws (CC) and washers (DD).






Option 3. (For Concrete Structure)

Mark and drill the anchor holes on the concrete structure, and then insert the anchors (EE). Mount the mounting bracket to the concrete structure with wood screws (CC) and washers (DD).



2. Install the Bulb

Install the Bulb (E26, Max 60W, not included).




Note:


1. To achieve dimming functionality, you need to use dimmable bulbs and a dimmer switch.
2. For bulbs with color temperature control, repeatedly switch “on” and “off” using the wall switch to change settings.


3. Install the Light Shade

Step 1: Pull down the fixing tab of lamp body (B).





Step 2: Clip one side of the tab onto the light shade (C) first, then secure the opposite side in place.






Step 3: Tighten the top nut to lock the fixing tab into position.






4. Assembled the Lamp Body

Tighten the cap nut downward, then tighten the screw on the cap nut.




5. Hang the Lamp Body

Hang the lamp body (B) on the mounting bracket (A).




6. Connect the Wires

Connect the wires from the fixture to the house supply wires with wire nuts (AA), ground wire (green, green/ yellow, or bare copper) to ground wire, neutral wire (white) to neutral wire, and hot wire (black) to hot wire. Wrap the connection with electrical tape.



7. Fix the Lamp Body

Push up the canopy to cover the mounting bracket (A), then use hex wrench (FF) to fasten the canopy screws.



Trouble Shooting

1. Missing / Broken Parts

· Make a list of the missing/broken parts according to the packing list, take photos for broken parts, then email us for free replacements.

2. Bulbs Do Not Light Up

· Check your power and switch to make sure it's power on.
· For regular bulbs, make sure it is connected to the ON/OFF wall switch, not the dimmer switch.
· Replace the bulb with a new one.

3. Bulbs Flicker

· If it is a dimmer switch, use a dimmable bulb.
· Replace the bulb with a new one.

4.Could Not Install / Assemble

· Take photos of the ceiling / fixture, contact seller for technical support.

Clean And Care

To clean, wipe the fixture with a soft cloth. Spraying from chemical cleaners can discolor the finish of the fixture.
Do not use scouring pads, powders, steel wool, or abrasive paper to clean this fixture.

Ordering Parts

Keep this manual for future reference, and in case replacement parts are needed. Available parts can be ordered from the place of purchase. Use exact wording from diagrams when ordering parts.