

Operate instructions

Start to use

Turn on lock

There are 2 groups password for you to use the cabinet lock at the first time. User code "1111" and Master lock "0000 0000", Both the user code and the master code are at latest 4-10 digits.

1. Input the right password you set (If you haven't changed, Please use the default password), then press "#" button to turn on lock.
2. If the password is correct, the green LED on.
3. Please pull the door during the green led on.

Remark: "#"button for confirmation; "C"button for elimination .

Turn off lock

Private type: Push the cabinet door to the close situation, then can turn off lock.

Public type: When cabinet lock at the state of opening (Latch/bolt at the state of retract) , push cabinet door to the state of closing, Input the password which you set, and press "#" button to confirm, Then can turn off lock(Input the password you set ,it can turn on lock again).

Change password

Default password is set up by the manufacturer, it is only used for the first time. Please change password in time for safety and make sure to remember your new password.

Change User code

Private type change use code

Step 1. Press the key of "#" twice.

Step 2. Input the old user password.

Step 3. Press the key of "#" One time.

Step 4. Input the new user password you want.,Press the key of "#" One time.

Then the green light will flash one time for Two seconds, At the same time, The lock-body will sound "Di——Di——! ". Now, the user password has been changed successful.