




## Pompeii Swivel Rocking Dining Chair



Item #.: 3502C02RE

Customer Service

[customerservice@americasbackyards.com](mailto:customerservice@americasbackyards.com)

Monday - Friday, 9:00AM – 5:00PM CST












Toll Free: 1-888-910-5646 Fax: (832)-201-9138

[www.americasbackyards.com](http://www.americasbackyards.com)

# WARNING

Please read instructions carefully and thoroughly before assembling. Check parts against the parts list to make sure you have all the parts needed for proper assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly. **DO NOT ATTEMPT TO ASSEMBLE IF PARTS ARE MISSING OR DAMAGED. IMPROPER ASSEMBLY MAY RESULT IN DAMAGE OR SERIOUS INJURY.**

**Place the chair on a non-abrasive flat surface to prevent scratching.**

PART #.	DESCRIPTION	PICTURE	QTY
A	Chair Seat		2
B	Chair Base		2
C	Seat Cushion		2
D	Back Cushion		2
E	Bolt		8
F	Metal Plate		8
G	Flat Washer		8
H	Lock Washer		8
I	Nut		8
J	Nut Cover		8
K	Wrench		1

1. Place the chair seat (A) on a non-abrasive flat surface. Align the holes on the support bar on the underside of the chair seat with the holes on the spring plates attached to the T-rocker that is pre-attached to the chair base (B). Make sure the arrow labels on the rocker mechanism and chair support bar are facing the same direction—towards the front of the chair. Insert bolts (E) through the metal plates (F), support bar, spring plate and the metal plates (F) as showed in the diagram. Secure bolts with flat washers (G), lock washers (H) and nuts (I). The support bar and spring plate should be sandwiched in between the metal plates (F).

**Warning:** Improper assembly may result in serious personal injury.

Once all the nuts and bolts are in place, securely tighten all the bolts (E) and nuts (I), including the ones at the front part on the rocker mechanism with the wrench (K). Cover all nuts with nut covers (J).

Place the seat cushion (C) and back cushion (D) on the swivel rocking dining chair. Test the swivel rocker gently. If the rocker does not rock properly, double check the assembly procedure, especially step 1.

**REPEAT ABOVE STEPS TO ASSEMBLE THE ANOTHER SWIVEL ROCKING DINING CHAIR.**

Your swivel rocking dining chair is ready for enjoyment.

