

ASSEMBLY INSTRUCTION

QUEEN HEADBOARD






QUEEN FOOTBOARD

QUEEN/KING SIDE RAILS

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

(We only recommend spraying cleaners on a rag, then gently wiping the surface clean. Never directly spray a mirror with cleaner to prevent overspray or pooling at the edge)

PARTS LIST


1		2		3	
Headboard(1 pc)		Footboard (1 pc)		Legs (2 pcs)	
4		5		6	
Side rail (2 pcs)		Slat(4 pcs)		Support (4 pcs)	

HARDWARE LIST				
NO.	Sketch	Description	Size	Q'ty
A		CSK Screw	4mm*32mm	8PCS

Note:

* Do not tighten the bolts until steps are complete.

STEP:1.Attach the legs to footboard bottom.
2.Attach the side rail to headboard and footboard.
3.Attach the support to the slat and tighten.
4.Attach the slat to the side rail using CSK screw(A) and tighten.



CAUTION: Changes or modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit Different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CLEANING INSTRUCTION

PAGE 1 OF 1

Clean the surface with a furniture polish and a soft cloth.

MADE IN VIETNAM